



ECOTAPE



ECOMAT

Manual wrapping machine for applying the ECOTAPE coating systems.

Modular design to apply corrosion and/or mechanical protection coating tapes in pipes of several diameters, from 4" (DN100). It is possible to adjust overlap and tape's tension to make easier a correct application.

For tapes with interleave film (3ply), the machine has the elements to collect it automatically. (Model C, with film collector)

DESCRIPTION

MODELS

DESCRIPTION	BASIC	BASIC	COMPLETE	COMPLETE
Model	ECM-B-150-C76	ECM-B-150-C41	ECM-C-150-C76	ECM-C-150-C41
Ø Pipe	≥ 4"	≥ 4"	≥ 4"	≥ 4"
Core	76mm	41mm	76mm	41mm
Max. Width tape	150mm	150mm	150mm	150mm
Weight (Kg.)	4,2	4,2	4,8	4,8
Collector	No	No	Yes	Yes

Note: all the models are interchangeable by the use of the corresponding accessories

BASIC OPERATING'S INSTRUCTION

STEP	MODEL	DESCRIPTION
1	ALL	Adjust the wheel's position over the pipe
2	B	Insert the roll in the shaft with adhesive side facing down
2	C	Insert the roll in the shaft with the interleave film side facing down
3	C	Fasten the interleave film to the collector by the fastener
4	ALL	Adjust the advance's angle to get the expected overlap
5	ALL	Begin the wrapping process adjusting the necessary tension

There is additional information at our operating instructions guide.
Ask according the model.